

# **PRE-OILED DECKING**

Parkside Timber decking is now available pre-oiled to provide protection during the installation process.

Our decking products are grown and manufactured in Australia for Australian conditions. Our decking is certified by internationally recognised PEFC - guaranteeing that all products are sourced from sustainably managed forests.





## **KEY BENEFITS**

- Pre-oiled decking means that all sides are coated providing protection during the installation process.
- Provides weather resistance and durability up to 8 weeks.
- Adds dimensional stability prior and during installation.

## **INSTALLATION**

- Store in a cool dry area 100mm off the ground before installation
- Install decking 400mm off the ground, with good ventilation beneath
- Ensure good surface drainage below the deck
- Holes should be predrilled and countersink
- Joists should span a maximum of 450mm centre to centre
- Allow minimum of 3-5mm gap for 86mm and 7mm gap for 135mm
- Must be coated top side within 8 weeks of installation. Refer finishing instructions.

For the complete installation guide, please visit our website: parksidetimber.com.au

QLD Spotted Gum (Hardness 11)

Karri (Hardness 9.0)

Jarrah (Hardness 8.5)

Hardness refers to the Janka rating which is the hardness level given to each species. The higher the number, the greater the hardness.



## **GRADES**

Standard & Better

## SIZES AND LENGTHS

86 | 135 x 19mm Random packs 1.5m to 5.7m



## DURABILITY

**QLD Spotted Gum** Class 1 Above Ground ACQ H3 Treatment

Karri · Jarrah Class 2 Above Ground



#### CERTIFICATION

Manufactured to comply with AS 2796

Fire rated in accordance with AS 3959

QLD Spotted Gum is fire rated to BAL 29

Karri and Jarrah can achieve BAL 29 when used in conjunction with non-combustible wall cladding and enclosed subfloor

Chain of Custody as per AS 4707

## **FINISHING INSTRUCTIONS**

- 1. After installation, thoroughly scrub with a timber cleaner.
- 2. Once dry, apply 2-3 coats of selected oilbased or water-based timber finish. Do not apply a mineral oil based finish.
- 3. Conduct maintenance inspections annually to ensure your timber is repelling water and the finish is in sound condition.
- 4. If maintenance is required, thoroughly scrub with timber cleaner and apply selected finish.

